Z and Q Signal Crib Sheet   INT before z code turns it in to a question as indicated

ZAL   - close at _____

ZBO   - I have Traffic! – Do You have Traffic? ZBO (# Prec. __) traffic for __

ZEE   - Request message be transmitted
ZEN   - this message delivered by separate tx to __
ZEU   - This is a DRILL Message!
ZEV   - Message Acknowledged! – Do You Acknowledge?

ZGN   - Nothing Heard! – Did You Hear? (list)

ZKA   - I am NCS! - WHO is NCS?
ZKB   - This is a Directed Net! - IS this a Directed Net?
ZKD   - Take Control of Net! – Shall I Take Control of Net?
ZKE   - I am Checking In! - Are there Any Check-Ins?
ZKJ   - I am Closing Down! – May I Close Down?
ZKS   - stations are keeping watch on...kHz (or MHz) (or are in net)

ZNR   - May be forwarded   ZNR UUUUU is always line 4 of CODRESS message
ZNY   - Do not forward unencrypted by radio or non - approved circuit
          UUUUU = unclassified
          EEEEE = unclassified but must be encrypted for transmission only to protect its contents.
       ZNR UUUUU is always line 4 of CODRESS message because the code groups
              are unclassified, non-FOUO, and don't require protection.

ZOE   - Send ME Your Message!
ZOF   - Relay This Message to (list)
ZOG   - Send This Message to (list) for 1) action, 2) information
ZOH   - Traffic Available is (list)! – What Traffic is Available?

ZUE   - Affirmative (Yes)!
ZUG   - Negative (No)!
ZUH   - Unable to Comply!
ZUJ   - Stand By!

ZWF - Incorrect!   ZWG   - Correct!

QRK   - intelligibility (print quality) report
          (1. Bad 2. Poor 3. Fair 4. Good 5. Excellent)
QRU   - Have you anything for me? - I have nothing for you
QSP   -Relay

IMI = repeat, say again
NR = "number"

K = OVER
KN = OVER (back to other station)
AR = OUT
AS = WAIT
AA = unknown station
NNNN = end of message